




Pinkwood PKjoists® Damaged Joist Repair – Added Joist

Damaged joist repair with added joist

When damage to a PKjoist® is beyond repair and the removal of the damaged joist is impractical, adding an additional PKjoist next to the damaged joist may be the best option. The following detail restores the floor performance provided that the damaged joist was uniformly loaded, and the span index of the subfloor sheathing is not exceeded.



Installation Notes

1. Use same joist depth and series as damaged joist.
2. Install joist adjacent to damaged joist.
3. Ensure added joist has sufficient bearing (1-1/2" minimum)
4. Glue exposed edges of top flange to subfloor on both sides.
5. Connect rim board to joist per fastener schedule if mating surfaces are in contact.
6. Add blocking at rim conditions if there is a gap between rim and joist end.
7. Remove and reinstall blocking at blocked conditions.
8. Connect subfloor to added joist per floor diaphragm fastening schedule.

If you have any questions, please contact XP-EWP for details.

Pinkwood® and PKjoist® are registered trademarks and not the property of XP-EWP. Contact their respective owners for information.

XP-EWP

14523 S. Palo Alto Drive,
Herriman UT 84096

Contact johnd@xp-ewp for more details

TECHNICAL BULLETIN
TB13

January 2026